

Step 5: Affix the Slat (M) to the side rail support wood and the center rail (E). Tighten all the 4 corner.