




Assembly Instruction **Item Code - Bentley (F2410)** **Imported by JCT Global**

Building 3 west 605 Zillmere Rd, Aspley QLD 4035




3S

BEFORE YOU START...


1. Chose a clean, level, spacious assembly area. Avoid hard surface that may damage the product.
2. Check and ensure that you have all required contents for complete assembly.
3. Always read the assembly instructions carefully before beginning assembly.
4. The packaging and contents can be a choking hazard, therefore keep out of reach of small children at all the times.

Step 1 Turn the sofa over and fit it with plastic feet.




This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

Step 2 Assemble the armless sofa and the right sofa first, then assemble the left sofa.



Step 2 Assembly complete



Disassemble

Step 1 First, lift the left sofa upwards and then move it to the left to disassemble it. Then, disassemble the armless sofa in the same way.

