


**BEFORE YOU START...**

1. Choose a clean, level, spacious assembly area. Avoid hard surface that may damage the product.
2. Check and ensure that you have all required contents for complete assembly.
3. Always read the assembly instructions carefully before beginning assembly.
4. The packaging and contents can be a choking hazard, therefore keep out of reach of small children at all the times

**Step 1 Join sofa by back connector**




**Step 2**

3EE/2EE:

- ① Remove the Power cord, power adaptor, Y-cord which are tied to the steel mechanism at the bottom.
- ② Connect the two ends of the Y-track to the plugs from the left arm facing recliner and the right arm facing recliner respectively.
- ③ Connect the other end of the Y-cord to the adaptor. Plug the power wire into the adaptor
- ④ Plug power cord into the available electrical outlet.

1E:

- ① Remove the Power cord and power adaptor which are tied to the steel mechanism at the bottom.
- ② Connect the end of the cord to the adaptor from the left arm facing recliner.
- ③ Plug the power wire into the adaptor. Plug power cord into the available electrical outlet.



PARTS LIST	
3EE/2EE:	
A: Power cord × 1	
B: Adaptor × 1	
C: Y-cord × 1	

PARTS LIST	
1E:	
A: Power cord × 1	
B: Adaptor × 1	

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

**Step 3 Assembly complete**

