

Assembly Instruction

Item Code - Tacoma (SK-NAG1013)

Imported by JCI Global


Building 3 west,605 Zillmere Rd,Aspley QLD 4035




BEFORE YOU START...

- 1. Chose a clean, level, spacious assembly area. Avoid hard surface that may damage the product.
- 2. Check and ensure that you have all required contents for complete assembly.
- 3. Always read the assembly instructions carefully before beginning assembly.
- 4.The packaging and contents can be a choking hazard, therefor keep out of reach of small children at all the times.

Step 1 Join sofa by back connector





please note:


Bracket "B"(Located on the seat frame of the sofa) inserts into Bracket "A" (Located inside the back frame of the sofa)

Step 2

3EE/E-Station:

- ①Remove the Power cord and reading lamp power supply which are tied to the steel mechanism at the bottom.
- ②Connect the power lumbar wire and headrest wire. Red to red, black to black.
- 3 Connect the power cord from one end of the reading lamp to the other end of the sofa.
- And reading lamp power plug, socket outlet, plug power cord into the available electrical outlet.
- ①Remove the Power cord which are tied to the steel mechanism at the bottom.
- Take out the wireless charging power supply placed in the console.
- 3 Connect the power lumbar wire and headrest wire. Red to red, black to black.
- (4) Connect the power cord from one end of the wireless charging to the other end of the sofa.
- **⑤Wireless charging power plug and plug power cord into the available electrical outlet.**
- (1) Remove the Power cord which are tied to the steel mechanism at the bottom.
- ②Connect the power lumbar wire and headrest wire. Red to red, black to black.
- 3And then plug power cord into the available electrical outlet.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision o instruction concerning the use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.



PARTS LIST PARTS LIST 3EE/E-Station: 2EECT: A: Power cord \times 1 A: Power cord \times 1 B: Wireless charging power supply \times 1 B: Reading lamp power supply \times 1

PARTS LIST A: Power cord × 1

Step 3 Assembly complete



Function: Switch Instruction

- 1. Type-c Charger
- 2. USB Charger
- 3. Open Recliner
- 4. Close Back to sitting position
- 5. Up Lumbar up
- 6. Down Lumbar down
- 7. Up Open the headrest
- 8. Down Close the headrest
- 9. Memory button II 10. Memory button I

